




**OLIMPIC SAILS**  
wings for your dreams



ROBERTDEAVES.UK



# TUNING GUIDE

 OLIMPICSAILS  VELERIAOLIMPICSAILS | [INFO@OLISAILS.IT](mailto:INFO@OLISAILS.IT) | [WWW.OLISAILS.IT](http://WWW.OLISAILS.IT)

ITALY | SPAIN | PORTUGAL | USA | HUNGARY | CROATIA



**OLIMPIC SAILS**  
wings for your dreams

- Leech tension is measured at 6020mm from top of mast to the forward edge of the boom band, with boom end on one boat side.
- The standard setting suggested is to keep maximum distance between centerboard and mast (maintaining an adequate leech tension) with strong wind and move them closer when the wind decreases.
- These information can be followed considering the subjective differences between sailors. The most important guide is the personal helm and boat feeling through different wind intensities

 <b>FINN TUNING TABLE</b> 			
<i>Wind Speed</i>	<b>DECK</b>	<b>CENTERBOARD</b>	<b>LEECH TENSION</b>
0-6 kt	30 mm	Forward	32,5 kg / 33 kg
6-8 kt	35 mm	Forward	33,5 kg
8-12 kt	40 mm	Forward	34 kg
12-16 kt	45 mm / 50 mm	Middle	34 kg
16-20 kt	50 mm /55 mm	Back	33,5 kg
20 kt +	55 mm	Back	33,5 kg

For any question you may have on tuning your Finn contact our Finn expert:

Alessandro MAREGA - [alessandro.marega@olisails.it](mailto:alessandro.marega@olisails.it)